



**Industrial
 Rivet &
 Fastener Co.**

| Diagram # | item | desc1 | Qty |
|-----------|---------------|---|-----|
| 1 | RK986-GN-0001 | TRACTION PISTON FOR RK-986 GUN | 1 |
| 2 | RK986-GN-0002 | TRACTION SLEEVE STOP FOR RK-986 GUN | 1 |
| 3 | RK986-GN-0003 | TRACTION SLEEVE STOP CIRCLIP FOR RK-986 GUN | 1 |
| 4 | RK986-GN-0004 | OIL WASHER (2 PCS.) FOR RK-986 GUN | 1 |
| 5 | RK986-GN-0005 | OIL BLEED SCREW (2 PCS.) FOR RK-986 GUN | 1 |
| 6 | RK986-GN-0006 | SPRING FOR RK-986 GUN | 1 |
| 7 | RK986-GN-0007 | SLEEVE GUIDE FOR RK-986 GUN | 1 |
| 8 | RK986-GN-0008 | REAR STOPPER SEAL FOR RK-986 GUN | 1 |
| 9 | RK986-GN-0009 | REAR PLUG SEAL FOR RK-986 GUN | 1 |
| 10 | RK986-GN-0010 | REAR STOPPER CIRCLIP FOR RK-986 GUN | 1 |
| 11 | RK986-GN-0011 | RUBBER PROTECTION FOR RK-986 GUN | 1 |
| 12 | RK986-GN-0012 | REAR PLUG FOR RK-986 GUN | 1 |
| 13 | RK986-GN-0013 | TRACTION SHAFT CIRCLIP FOR RK-986 GUN | 1 |
| 14 | RK986-GN-0014 | HYDRAULIC CONNECTOR WASHER FOR RK-986 GUN | 1 |
| 15 | RK986-GN-0015 | HYDRAULIC CONNECTOR FOR RK-986 GUN | 1 |
| 16 | RK986-GN-0016 | TRIGGER SEAL FOR RK-986 GUN | 1 |
| 17 | RK986-GN-0017 | MAIN BODY FOR RK-986 GUN | 1 |
| 18 | RK986-GN-0018 | TRIGGER SPRING FOR RK-986 GUN | 1 |
| 19 | RK986-GN-0019 | TRIGGER GUIDE FOR RK-986 GUN | 1 |
| 20 | RK986-GN-0020 | TRIGGER FOR RK-986 GUN | 1 |
| 21 | RK986-GN-0021 | AIR CONNECTOR FOR RK-986 GUN | 1 |
| 22 | RK986-GN-0022 | TUBE PROTECTION FOR RK-986 GUN | 1 |
| A | RK986-GN-2003 | NOSEPIECE HOLDER UNIT FOR RK-986 | 1 |
| B | RK986-GN-2009 | NOSEPIECE HOLDER STOP FOR RK-986 | 1 |

Industrial Rivet & Fasteners Co. offers a comprehensive tool service and repair program, for details contact your local area sales representative or call direct:



200 Paris Avenue
 Northvale, NJ 07647
 Tel: (201) 750-1040
 Fax: (201) 750-1050